
XLR18LE-XLR25LE



SCOPA SENZA FILI
CORDLESS STICK CLEANER
ASPIRATEUR BALAI SANS FIL
STAUBSAUGER KABELLOS
DRAADLOZE STEELSTOFZUIGER
ESCOBA INALÁMBRICA
ASPIRADOR VERTICAL SEM FIO
ΗΛΕΚΤΡΙΚΟ ΣΚΟΥΠΑΚΙ ΧΩΡΙΣ
ΚΑΛΩΔΙΟ
БЕСПРОВОДНОЙ ПЫЛЕСОС
ЗАРЯДТАЛҒЫШ ҮТІК
ТАЗАЛАҒЫШЫ
VEZETÉK NÉLKÜLI SEPRŰ
BEZDRÁTOVÝ SMETÁK
BEZKÁBLOVÁ METLA
BEZPRZEWODOWY SZCZOTKOWY
KABLOSUZ SÜPÜRGE

DeLonghi

IT

pag. 9

EN

page 11

FR

page 13

DE

S. 15

NL

pag. 17

ES

pág. 19

PT

pág. 21

EL

σελ. 23

RU

стр. 25

KZ

Бет. 28

HU

old. 31

CS

str. 33

SK


str. 35

PL





str. 37

TR




say. 39














A









B





















Svuotamento - Emptying - Vidage - Leerung - Ledigen - Vaciado - Esvaziamento - Αδειασμα - Очистка - Босату - Kiürítés - Vyprazdňování - Vyprázdnenie - Opróżnianie - Boşaltılmas



Pulizia - Cleaning - Nettoyage - Reinigung - Reiniging - Limpieza - Limpeza - Καθαρισμός - Уход - Тазалая - Tisztítás - Čištění - Čistenie - Czyszczenie - Temizlik





Rimozione batteria - Removing the battery - Retrait de la batterie - Batterieentfernung - Verwijdering batterij - Extraer la batería - Remoção da bateria - Αφαίρεση μπαταρίας - Утилизация аккумулятора - Батареяны алу - Tisztítás - Vytímaní baterie - Vybrať batérie - Wyciąganie baterii - Pilin çıkarılması

