




































www.tefal.com

	 g	 min	 °C		
	300 - 700	15 - 20	200	✓	
	300 - 800	22 - 32	180	✓	
	300 - 800	22 - 27	180	✓	
	100 - 500	9 - 17	180		
	400	8 - 12	180		
	100 - 500	12 - 19	180		
	1200	60	180		
	350	15 - 17	140		
	100 - 600	7 - 12	200		
	300	16 - 20	200		
	200	8-10	200	✓	
	120	8	180		
	4 x 100	18 - 22	180		

NCO0145698

Tefal®



Easy Fry classic

www.tefal.com